

Stage needs:

- Height-adjustable DJ deck.(approximately 2mx1m)
- Soundcard outputs are double mono 1/4" un-balanced jacks
- DI thru at main voice, main voice goes to PA and to laptop input (thru the DI).
- Mic stand should be a short one (kick drum type) and placed on the table.

